

March 23, 1964
Rewritten August 20, 1964

ENGINEERING MEMORANDUM #56 Model B-11, B-12

TO: J. Stout, P. Visser, E. Wilson, J. Coleman, S. Hori, E. Horrigan,
K. Luke, F. Leamy (3), R. McCulfor, R. Smith, C. Cornwell,
E. Nelson, J. Copeland, T. Bedard, J. Temple (4), K. Bothe,
L. Hilsky (4), A. Radke (3), D. Markin, B. Herrington (8),
W. Asselin, D. Bach, F. Baldwin, A. Goedhart, S. Megyesi.

FROM: R. G. Fuller

SUBJECT: PARKING BRAKE CABLE RETAINER AT REAR SPRING

Abandoning all previous methods to retain the parking brake cable housing away from the rear spring inhibitor, install two springs, one each side, 94348 in the following manner:

Hook one end of spring over cable, after all other installation operations are complete, and pull spring out hooking the other end around the forward leg of the inner spring "U"-Bolt. This will hold the cable on inner side of the inhibitor rubber, providing protection for said rubber.

Increased quantity for 94348 Spring and corresponding reduction in quantity for 80345 Clamp are being processed.